



HOW TO GET NOZZLE CLEANER PART NAME

CHANGER
&
DRESSER





PART NAME

EXAMPLE OF FULL PART NAME.

“NCAM-03-T-26-26-AR16”

1. Nozzle Cleaner Model #

2. Type of Nozzle

3. Upper Roller Size X

4. Lower Roller Size Y


5. Reamer Size

YOU WILL NEED TO FILL OUT

“NCAM-03-(TYPE OF NOZZLE)-(X ROLLER)-(Y ROLLER)-AR(REAMER SIZE)”



2. NOZZLE TYPE

Nozzle Type: S type, T type, TL type, D type



3. X ROLLER SIZE



Measure the "X" outer diameter of the nozzle as shown in the picture below



X axis Roller			
NO	Paert Number	Nozzle O.D	Inscription
1	NCAM-X20	Φ 20	X 2 0
2	NCAM-X21	Φ 21	X 2 1
3	NCAM-X22	Φ 22	X 2 2
4	NCAM-X23	Φ 23	X 2 3
5	NCAM-X24	Φ 24	X 2 4
6	NCAM-X25	Φ 25	X 2 5
7	NCAM-X26	Φ 26	X 2 6
8	NCAM-X27	Φ 27	X 2 7
9	NCAM-X28	Φ 28	X 2 8
10	NCAM-X29	Φ 29	X 2 9
11	NCAM-X30	Φ 30	X 3 0

4. Y ROLLER SIZE



Measure the “Y” outer diameter of the nozzle as shown in the picture below



Y axis Roller			
NO	Part Number	Nozzle O.D	Inscription
1	NCAM-Y15	Φ 15	Y 1 5
2	NCAM-Y16	Φ 16	Y 1 6
3	NCAM-Y17	Φ 17	Y 1 7
4	NCAM-Y18	Φ 18	Y 1 8
5	NCAM-Y19	Φ 19	Y 1 9
6	NCAM-Y20	Φ 20	Y 2 0
7	NCAM-Y21	Φ 21	Y 2 1
8	NCAM-Y22	Φ 22	Y 2 2
9	NCAM-Y23	Φ 23	Y 2 3
10	NCAM-Y24	Φ 24	Y 2 4
11	NCAM-Y25	Φ 25	Y 2 5
12	NCAM-Y26	Φ 26	Y 2 6
13	NCAM-Y27	Φ 27	Y 2 7
14	NCAM-Y28	Φ 28	Y 2 8

5. REAMER SIZE

Please measure I.D. of the nozzle as shown below



Please check the contact tip size and see if it will fit into reamer by checking “Reamer I.D”

Reamer				
Part Number	Nozzle I.D	Reamer O.D	Reamer I.D	Inscription
NCAM-AR12	φ12	φ10.4	φ9.2	AR12
NCAM-AR13	φ13	φ11.4	φ9.4	AR13
NCAM-AR14	φ14	φ12.4	φ10	AR14
NCAM-AR15	φ15	φ13.4	φ10	AR15
NCAM-AR15.5	φ15.5	φ14	φ11	AR15.5
NCAM-AR16	φ16	φ14.4	φ11	AR16
NCAM-AR17	φ17	φ15.4	φ12	AR17
NCAM-AR18	φ18	φ16.4	φ13	AR18
NCAM-AR19	φ19	φ17.4	φ14	AR19

Thank you for your time!!

Changer & Dresser Corp.

Tel : 256.832.4392

Fax : 256.832.4393

www.changer-dresser.com

**CHANGER
&
DRESSER**

